



INSTALLING A HEAT SCREEN AND A PLASTERBOARD STRUCTURE OVER A BIO-FIREPLACE DALEX C2-70



- - cold air
 - - warm air
 - - hot air
- Important!** Zone 1 must withstand heating up to 80° C. Zone 2 must be made of fireproof materials (stone, concrete, brick, foam concrete, heat-resistant plasterboard followed by plaster). Installing glass on a biofireplace - required. For an automatic bio-fireplace, provide a Euro plug socket nearby type.

INSTALLING A HEAT SCREEN AND A PLASTERBOARD STRUCTURE OVER A BIO-FIREPLACE DALEX C2-70



— - cold air **Important!** Zone 1 must withstand heating up to 80° C. Zone 2 must be made of fireproof materials (stone, concrete, brick, foam concrete, heat-resistant plasterboard followed by plaster). Installing glass on a biofireplace - required. For an automatic bio-fireplace, provide a Euro plug socket nearby type.

— - warm air

— - hot air